Installation instructions

For the installation of the library we will proceed as follows:

- The .rfa files and matching .txt files must be moved to the location of your choice. Make sure that the .rfa file and matching .txt file are always in the same folder.
- The supplied .ies files must be moved to the correct folder: C:\ProgramData\Autodesk\ApplicationPlugins\Witas RME_BE_NL Localiser.bundle\IES
- ETAP series use Type Catalogs, which enable you to only load the desired types of a specific luminaire into your project, which results in a smaller project size. This does imply, however, that the series cannot be loaded using 'drag and drop', since the type catalog will then be ignored.
- The series can be loaded into the project through Insert > Load Family. When browsing for the correct location, the desired series can be selected. When clicking on 'open', the desired types can be selected within the series, with the use of filters. When clicking on 'ok', the selected types will be loaded into the project and can be chosen through the relevant category.